


快速入门指南

Quickstart
Guide



4
设置音乐

打开 Sonos 控制器，进入音乐选择菜单

- 1 添加音乐服务 — 通过它添加您的在线音乐服务。
- 2 音乐库 (本地共享音乐) — 播放存储在您的计算机或任何本地网络硬盘 (NAS) 中的音乐。建议您使用 Mac 或 PC 上的 Sonos 控制器软件预先配置并添加您的本地音乐，方法是从设置菜单中选择音乐库 (本地共享音乐) 设置。
- 3 电台 — 访问众多互联网电台。
有关完整的音乐选择列表，请访问 www.sonos.com/music

希望了解更多

网址 sonos.com/support	技术支持热线 中文: +86 400 664 9889 英文: +1 800 680 2345
邮件 support@sonos.com	
用户手册及常见问题解答 sonos.com/guides	



设置

要将 Sonos PLAY:5 添加到现有的 Sonos 系统，只需接通电源，然后从移动设备 Sonos 控制器的“设置”菜单中选择“添加播放器或 SUB”，或使用 Sonos Mac 或 PC 控制器从“管理”菜单中选择“添加播放器或 SUB”。

要设置全新的 Sonos 系统，请参考步骤 1 - 4。详细安装指导请参考 www.sonos.com/support/players

1
接通 Sonos PLAY:5 的电源

2
可选 (如果您没有
BOOST 请跳过此步)

如果您购买了 Sonos BOOST，请用包装箱内的网线连接 BOOST 任意网口到家用无线路由器的 LAN 口，然后接通电源。

将 Sonos BOOST 或任意一台 Sonos 音响用网线连接到路由器可以建立专门用于 Sonos 系统的稳定的专用无线网络。否则 Sonos 将直接连接您家中现有的无线网络。更多信息，请访问 www.sonos.com/rock-solid-wireless

3
下载和安装
Sonos 控制器软件

在设置您的 Sonos 系统之前，您需要先下载并安装 Sonos 控制器软件（参考下图及说明），然后打开并按照屏幕上的指示设置 Sonos 系统。

- 在设置过程中：
- 系统会提示您按下然后松开 Sonos 产品上的一个或多个按钮，以便将该产品添加到 Sonos 系统。
 - 如果您选择用网线将 Sonos 产品连接到无线路由器，请在设置过程中先添加该产品。
 - 系统可能会提示您更新 Sonos 产品。此操作需要几分钟时间，具体取决于您的网络连接状况。
 - 在所有设备设置完成后，您会被要求使用常用的邮件地址和所在国家来注册您的 Sonos 系统。请您务必完成注册，以开启所在国家的在线音乐服务及获取免费的软件更新。



4
设置音乐

打开 Sonos 控制器，进入音乐选择菜单

- 1 添加音乐服务 — 通过它添加您的在线音乐服务。
- 2 音乐库 (本地共享音乐) — 播放存储在您的计算机或任何本地网络硬盘 (NAS) 中的音乐。建议您使用 Mac 或 PC 上的 Sonos 控制器软件预先配置并添加您的本地音乐，方法是从设置菜单中选择音乐库 (本地共享音乐) 设置。
- 3 电台 — 访问众多互联网电台。
有关完整的音乐选择列表，请访问 www.sonos.com/music

希望了解更多

网址 sonos.com/support	技术支持热线 中文: +86 400 664 9889 英文: +1 800 680 2345
邮件 support@sonos.com	
用户手册及常见问题解答 sonos.com/guides	

Set it up

Add to an existing Sonos system:

Just plug it in and select Settings ► Add a Player or SUB from the Sonos app on your mobile device, or select Manage ► Add a Player or SUB when using the Sonos app for Mac or PC.

Set up a new Sonos system:

To set up a new system, follow steps 1-4 below.

1
Connect your Sonos
PLAY:5 to power

2
Optional

If you purchased a Sonos BOOST, connect it to your router now with an Ethernet cable (supplied) and plug it into power. Otherwise, please skip this step.

Note: Connecting a Sonos BRIDGE, BOOST or Sonos player to your router with an Ethernet cable creates a separate rock-solid wireless network exclusively for your Sonos speakers. If you don't connect the Ethernet cable, Sonos joins your home's wireless network. For more information, go to www.sonos.com/rock-solid-wireless.

3
Download a Sonos
controller app

The Sonos controller app is required to set up your Sonos system (download instructions below). Please download the app, launch it, and then follow the on-screen prompts to set up your Sonos system.

- During the setup process:
- If you are connecting a Sonos product to your router, please add it first during the setup process.
 - You will be prompted to press and release one or more buttons on your Sonos products to add them to your Sonos system.
 - You may be prompted to update your Sonos products. This can take several minutes depending on your network connection.
 - You will be prompted to register your Sonos system. Be sure to register to receive free future software updates as well as music selections specific to your country.
- Mobile / Tablet (recommended)
Download the Sonos controller app from the store on your device
- Mac / PC
Download the Sonos controller for Mac or PC from www.sonos.com/install

4
Play music

Make a selection from the Sonos music menu.

- 1 Radio. Select from more than 100,000 free Internet radio stations, podcasts and shows.
- 2 Add Music Services. Explore and manage your music services.
- 3 Music Library. Play music stored on your computer or any Network-Attached Storage (NAS) device. If you have music on your computer, use the Sonos controller app for Mac or PC to set up your music library.
For a full list of music choices available in your country, go to www.sonos.com/music

Ask us

Website sonos.com/support	Telephone China (Mandarin): +86 400 664 9889 China (English): +1 800 680 2345
Email support@sonos.com	
Product User Guides sonos.com/guides	

SONOS

