Playbar

クイックスタートガイド

Sonosアプリをダウンロードする Playbarの設定およびコントロールに使用します。









Sonosをすでにお持ちですか?

Sonosアプリを開き、「詳細」>「設定」>「Player またはSubを追加」を選択します。



SONOS

 \circ

家全体にあふれる音楽を楽しむ Sonosアプリやあなたの声を使って、音楽サービスのオーディオを再生、 コントロールします。Playbarからもタッチ操作でコントロールできます。



お客様サポート

Sonos App:

電話:

サポート&情報

0120 63 5220

Website:

sonos.com/support

Email:

support@sonos.com

Twitter:

@SonosSupport

製品ユーザーガイド:

sonos.com/guides

SONOS®

© 2018 Sonos Inc. All rights reserved. Sonos、Playbar、全てのSonos製品名およびスローガンは、Sonos, Inc. の商標 または登録商標です。Sonosは米国特許商標庁登録済みです。

「Works with Apple」のラベルが付いたアクセサリは、そのラベルが示す技術に対応 するよう設計された製品であり、Appleが定める性能基準に適合していることをデベ ロッパが認定済みです。

Appleは米国および他の国々で登録されたApple Inc.の商標です。



Playbar

Quickstart Guide

Download the Sonos app
You'll use it to set up and control your Playbar.





Already have Sonos?


Open the Sonos app and choose

More > Settings > Add a Player or Sub.



Fill your home with sound

Play and control the audio from your TV using the Sonos app, your TV remote, or the touch controls on your Playbar.



Need help?

Sonos App: Help & Tips **Telephone:** 0120 63 5220

Website:

sonos.com/support

Email:

support@sonos.com

Twitter:

@SonosSupport

Product User Guides:

sonos.com/guides

SONOS®

© 2018 Sonos Inc. All rights reserved.

Sonos, Playbar and all other Sonos product names and slogans are trademarks or registered trademarks of Sonos, Inc. Sonos Reg. U.S. Pat & TM Off.

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards.

Apple is a trademark of Apple Inc., registered in the U.S. and other countries.